


# Menu Panel Stereo Control

This submenu is available with Handheld Panel MLM990H and Spa Side Panel MLM990S with software version 1.3.0 or higher.



**If a Jensen Stereo® is installed in your spa, the menu panels can control the basic stereo functions. From the Home screen, highlight Music and press Select. The radio menu will appear.**



**To activate a function, highlight it (using the navigation keys), then press Select.**

**Power:** Highlight Power and press Select to turn power on or off.



**Mode/Sel:** Sirius/iPod/Aux/Radio.

**Band:** FM 1, FM 2, FM 3, AM 1, AM 2.

**▶II/Mute:** Pause in CD or iPod mode. Mute in Radio, AUX, or Sirius mode.

**Info:** Provides media information when connected to an iPod® or Sirius®.

**Home:** Returns to the panel's Home screen.



**The Volume, Tune, and Seek controls are assigned an up and down value (plus and minus).**

⊖ Vol ⊕

To decrease the Volume by one level, select the minus icon, then press Select.  
To increase the Volume by one level, select the plus icon, then press Select.

⊖ Tune ⊕

To Tune to a station, select the minus or plus icon, then press Select.  
In Tune mode, each press of the Select button increases or decreases the radio station frequency.

<⊖ Seek ⊕>

To Seek a radio station, select the minus or plus icon, then press Select.  
The radio will seek down the frequency scale when minus is highlighted.  
The radio will seek up the frequency scale when plus is highlighted.  
Seeking will stop once a strong signal is found.

**Note: For a more detailed description of the features of these controls, consult the Jensen stereo manual.**

